




Lenovo Yoga 2 11" Speakers Replacement

This guide will show you how to safely remove faulty speakers and replace them.

Written By: Peyton Leeson





TOOLS:

- [1.5mm Hex Screwdriver](#) (1)
 - [Magnetic Project Mat](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Back Panel




- With a 1.5mm hex screwdriver, remove ten 6.35mm screws from the back of the laptop

Step 2




- Carefully separate back panel from laptop.

Step 3 — Speakers





- Once you complete the prerequisite guide, locate the two speakers.

Step 4




- Using a Philips 00 Screwdriver, remove the four 4.762mm screws that hold the speakers in place (two for each speaker).

Step 5



- Locate and carefully detach the clips that connect each speaker to the computer.

Step 6



- Now that the speakers are completely free from the computer, you are able to remove each speaker and replace it.

To reassemble your device, follow these instructions in reverse order.

